


Guidelines on choosing the size of a sling

ABC Slings



	Kids	Kids	Kids	XS	S	M	L	XL	2XL	3XL
	4 - 6	6 - 10	10 - 14							
H	45 - 60	55 - 70	68 - 80	75 - 82	80 - 87	85 - 92	90 - 97	95 - 102	95 - 102	95 - 102
W1	25 - 30	28 - 35	33 - 38	33 - 37	36 - 40	39 - 43	42 - 45	45 - 49	48 - 52	54 - 58
W2 ^{x)}		60 - 95	65 - 100	70 - 105	75 - 110	80 - 120	90 - 130	100 - 140	110 - 150	
W2 ^{xx)}		28 - 35	33 - 38							

W2 = Chest measurements

x) *Guideline for choosing Active Trainer*

xx) *Guideline for choosing Active Vest Kids*

All dimensions in cm